

Installation of PC Software for Controlling RE-C700

- Using Data Files in the USB Memory Stick Attached to RE-C700 -

- (1) Make copy of file folder [RE-C700-APL-231024A] in the USB memory stick and paste it on the desktop of your PC.

【Data folder in the USB memory stick】



【Data files in the folder [RE-C700-APL-230921]】

名前	更新日時	種類	サイズ
230917_Soft Manual_RE-C700PG.pdf	2023/09/21 13:52	Microsoft Edge P..	705 KB
230917_Soft Manual_RE-C700SG.pdf	2023/09/21 13:50	Microsoft Edge P..	210 KB
CDM212364_Setup.exe	2021/07/12 13:11	アプリケーション	2,212 KB
RE-C600ソフトウェアインストール方法(和・英)_2301...	2023/01/11 9:55	Microsoft Edge P..	86 KB
RE-C700-PRG-MOD-V3AC.exe	2023/09/20 18:04	アプリケーション	46 KB
RE-C700-SIG-MOD-V3A.exe	2023/09/19 9:11	アプリケーション	24 KB

- (2) Install the driver for USB connection to your PC using application file [CDM212364_Setup.exe] in the folder.

<SINGLE-MODE>

- (3)-1 Create a shortcut of application file [RE-C700-SIG-MOD-V3AA.exe] on your desktop.

<PROGRAM-MODE>

- (3)-2 Create a shortcut of application file [RE-C700-PRG-MOD-V3AF.exe] on your desktop.

- (4) Connect AC adaptor to RE-C700 and then connect with USB cable (USB-A/USB-microB).

- (5) Click on the shortcut of [SINGLE or PROGRAM-MODEの * * * *.exe] to run the program.

When you find **CONNNECTION - OK -** the display, installation is successfully done.